

# Marine Paint Manual

Reference No. : 16 - 05  
Issue Date: April 2010 (ES)

## NEOGUARD BULCON

A super high-build, durable surface tolerant pure epoxy anticorrosive which has excellent substrate wettability and can be applied to hand prepared surfaces as well as directly over existing coatings for maintenance and repair. It can be applied virtually anywhere, and even a single coat is effective in areas where heavy corrosion is anticipated or in places already rusted or pitted, providing high performance of rust protection.

Suitable Use	For Limited parts of exposed areas, immersed area, internal areas and other ship areas (welding lines, edges, etc.)		
Type	Pure epoxy (Super high build / Surface tolerant / Two-pack)		
Color	Light Cream		
Gloss	Flat		
Volume Solids	90 ± 2% (ISO3233:1998)		
Typical Dry Film Thickness	1.0 ~ 2.0 mm		
Approx. Wet Film Thickness	1.1 ~ 2.2 mm		
Theoretical Coverage	0.90 m <sup>2</sup> / L ( 1mm )		
Drying Time	Surface Dry	4 hours (5 )	2 hours (20 ) 1 hour (30 )
	Dry Hard	48 hours (5 )	16 hours (20 ) 8 hours (30 )
	Full Cure	14 days (5 )	7 days (20 ) 5 days (30 )
Interval before Overcoating ( by self )	Min.	48 hours (5 )	24 hours (20 ) 16 hours (30 )
	Max.	7 days (5 )	5 days (20 ) 3 days (30 )
Thinner	- See Note 3)		
Application Method	Brush / Spatula		
Mixing Ratio by Weight	BASE 1.5 / HARDENER 1		
Pot Life after Mixing	2 hours (5 ) 1 hour (20 ) 30 minutes (30 )		
Typical Package	5 kg (BASE 3 kg, HARDENER 2 kg) Package may vary from country to country.		
Japan Local Brand	BULCON		
Flash Point	BASE 24 , HARDENER 28		
Surface Preparation	Remove rust or loose paint film with wire brush, chipping hammer, power brush, disc sander etc. All surfaces to be coated should be clean, dry and free from contamination. High pressure fresh water wash and remove all oil / grease, soluble contaminants and other foreign matters.		

# Marine Paint Manual

NEOGUARD BULCON

Issue Date: April 2010 (ES)

## Safety

Take precautions to avoid skin and eye contact (i.e. gloves, goggles, face masks, barrier creams etc.)  
Proper ventilation and protective measures must be provided during applications and drying period to keep solvent vapor concentrations within safe limits.  
Prior to use, obtain, consult and follow the MSDS for this product concerning health and safety information.

### < Note >

- 1) The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.
- 2) Thoroughly mix Base and Hardener in specified amount with a mixing stick, a mixing knife, a spatula, etc.
- 3) In order to secure the film thickness, do not add thinner for dilution in principle.
- 4) Pot life at 20 is 1 hour. At high temperatures such as in summer, only the amount needed for each application should be mixed.
- 5) Make sure to keep the designed film thickness (Standard thickness : 1 mm) by using a brush, a spatula, etc.
- 6) Store the paints in paint store.